



Cleaning & Maintenance Guideline Interlocking Indoor Rubber Flooring

A) Post Installation Cleaning:

- When installation is complete, sweep floor to remove any debris then vacuum thoroughly to remove all surface dust and dirt.
- Damp mop using a neutral PH cleaner diluted with warm water using a microfiber mop. (See dilution rates on label).
 - Use a two-bucket system and change the water frequently.
 - Do not use any oil base cleaners as they will deteriorate the mats.
- If floor has been unprotected during construction and an excessive amount of dirt or dust is present additional cleaning with an auto scrubber may be required.
 - An RPM of 185 and brush pressure between 35lbs and 80lbs are recommended.
 - If disc type equipment is used, be sure to use a soft nylon brush, not a pad.
- Do not flood floor.
- Allow to dry thoroughly.
- Apply a treatment of an acrylic polymer floor coating according to the instructions on the label if desired.

B) General Maintenance:

Sealed/Non-Sealed Floors

- Typically, Rubber King Commercial products require less than other types of flooring.
 - Sweeping then damp mopping with a microfiber mop is the preferred method.
 - Do not use a string mop.
 - Use a two-bucket system with a neutral PH cleaner and change water frequently.
 - Products containing solvents and acids will attack the composite structure of the rubber flooring and cause deterioration.
 - Sealants, waxes, etc. can alter the surface characteristics and appearance.
 - Rubber King Commercial does not assume any responsibility for damages caused by chemical additives.
 - If an acrylic polymer protective floor coating is used, be sure to apply a coating after cleaning.

C) Floor Treatment

- For most installations, it is not necessary to seal or coat Rubber King Commercial Products.
 - Contact Rubber King Commercial supplier for the correct choice in your application.
- An acrylic polymer floor coating is recommended to improve the visual effects of shade variation and uneven distribution of color granules.
 - See label for installation instructions.

For additional information or technical assistance, please contact your Rubber King Commercial supplier.

Rubber King Commercial
Website: www.rubberking.com

Tol Free: 1-855-663-1520
E-mail: commercial@rubberking.com